

Information on Barryvox VS 68, VS 2000, VS 2000 Pro

Please direct all enquiries regarding sales and repair of those beacons to:

Girsberger Elektronik AG
Customer Service Barryvox
Mettlenstrasse 33b

8193 Eglisau / Schweiz

Tel. ++41 (0)44 867 00 49
Fax ++41 (0)44 867 31 12

barryvox@girsberger-elektronik.ch
www.girsberger-elektronik.ch

For your own safety, please observe the following rules:

Before departure:

- Run a self test (rotary knob on T position for at least 10 seconds), replace batteries if required.
- Run a group test, i.e. check your beacon against another beacon.

If not using the beacon for an extended period of time:

Remove the batteries from the compartment. Run out batteries can cause irreparable damage.

Periodic checkup (full test):

We recommend that you have your beacon checked at least every three years at our repair center. If you would like to have a perfect beacon at the start of the season, we recommend that you have the checkup done in between the seasons (June to September).

If you mail in a Barryvox device, please proceed as follows:

For every type of device, there is a repair order form, which you may obtain from us or download from our internet site **www.girsberger-elektronik.ch**.

Please complete one form for every device that you are sending in. This makes our work easier and avoids unnecessary callback. The services, prices and terms of business can be found on the repair order form.

We would like to point out that all or liability and warranty is terminated immediately if any repair or other modifications are applied by unauthorized persons.